

Aboveground Single-wall Storage Tank Installation & Testing Instructions



Highland Tank

Scope

These instructions apply to stationary, factory-assembled, aboveground single-wall vertical and horizontal steel tanks for the storage of stable, flammable and combustible liquids at normal atmospheric pressure. Because tank installation is a specialized craft, it is assumed that those using these instructions will have knowledge of, and possess the skills and equipment necessary to, install this type of aboveground steel storage tank properly and safely. These instructions concern only the handling and testing of the tank upon arrival at the site and its placement and are not intended to address piping, utility hookup, etc. details pertaining to installation of the tank.

Instructions

1.0 Tank Site

1.1 The foundation for the tank must be designed to support the tank plus 100% of the weight of the maximum amount of product the tank will be storing. The foundation may be comprised of concrete, asphalt, gravel or other stable material and must include provisions in its design to prevent tank movement. The foundation design must also include provisions for draining surface water away from the tank to minimize corrosion.

1.2 For tank installations without cathodic corrosion protection, a static electricity grounding system should be installed for the tank in accordance with applicable electrical and fire code standards. Tanks must be grounded to protect them from lightning damage.

1.3 For tank installations with cathodic corrosion protection, consult applicable standards (i.e., National Association of Corrosion Engineers) to provide that tank with appropriate protection from static electricity without disruption of corrosion protection.

1.4 Consult National Fire Protection Association publication NFPA, the Uniform Fire Code or the International Fire Code, and your local fire marshal and building inspectors for all applicable codes and restrictions such as spacing from buildings, property lines, public ways, etc.

1.5 Tanks located in areas subject to flooding must be protected against floatation.

1.6 Aboveground tanks should not be located above underground utilities or directly beneath overhead power lines.

1.7 The tank shall be protected from vandalism and accidental damage in accordance with all applicable codes.

2.0 Tank Handling

2.1 *Do not handle or install tank without having knowledge and experience in procedures involved with proper and safe installation of an aboveground tank used for storage of stable, flammable and combustible liquids. Reliance on skilled, professional installers is an important factor in avoidance of tank damage and system failures.*

2.2 Equipment for handling the tank shall be of adequate size to lift and set the tank. *Do not drop or drag the tank.*

2.3 Tanks shall be carefully handled using cables or chains of adequate length and size attached to the tank lifting lugs provided.

2.4 *Do not handle or move the tank unless it is empty.*

2.5 This is a stationary tank. *Do not use this tank for transport of any product.*

3.0 Testing

For horizontal tanks go to Section 3.1. For vertical tanks, go to Section 3.2.

3.1 Air Pressure Test Procedure for HORIZONTAL, Aboveground Tanks


3.1.1 Install test piping as shown in Figure 1. Temporarily plug, cap or seal off remaining tank openings to hold pressure. If tank is equipped with a long-bolt manhole for emergency venting, clamp lid as required using C-clamps; tighten securely and/or if equipped with standard emergency vents, remove emergency vents and cap openings to hold tank pressure as required.

CAUTION: The regulated air supply test pressure used for this test is not to be less than 3 psig (21 kPa) nor more than 5 psig (35 kPa). **Use only calibrated diaphragm type air pressure gauges with a zero to 10 psig dial span.** Set pressure relief valve in test air supply line at 4.5 psi.

CAUTION: Do not leave pressurized tank unattended.

WARNING: Do not stand in front of tank heads or fittings when pressurizing tank.

Figure 1



3.1.2 Close valve A.

3.1.3 Connect regulated test air supply line to test piping as shown in Figure 1.

CAUTION: Check to see regulated test air supply line pressure is properly set before proceeding.

3.1.4 Slowly open valve A to pressurize the tank. Pressure gauge should indicate test air pressure of 3 psig minimum to 5 psig maximum.

3.1.5 Close valve A. Disconnect regulated test air supply line from test piping.

3.1.6 Hold test pressure in tank for 1-hour minimum. A steady drop in pressure reading on the gauge indicates that there may be a leak in the tank.

3.1.7 Apply approved leak test solution to tank exterior surfaces, welds, fittings, etc. Check for leaks. No leaks are allowed, if leaks are found, notify Highland Tank, if no leaks are found, testing of the tank is complete. Proceed with instructions.

3.1.8 Slowly open valve A to release test air pressure from the tank.

3.1.9 With tank depressurized, remove test piping, temporary plugs, caps and seals. Reinstall emergency relief vents, etc. If tank is equipped with an emergency vent long-bolt manhole, remove C-clamps.

3.2 Air Pressure Test Procedure for VERTICAL, Aboveground Tank or rectangular tanks other than Fireguard®

3.2.1 Install test piping. Temporarily plug, cap or seal off remaining tank openings to hold pressure. If tank is equipped with a long-bolt manhole for emergency venting, clamp lid as required using C-clamps; tighten securely and/or if equipped with standard emergency vents, remove emergency vents and cap openings to hold pressure required.

CAUTION: The regulated test air supply pressure used for this test is not to be less than 1-1/2 psig (10 kPa) nor more than 2-1/2 psig (17 kPa). **Use only calibrated diaphragm type air pressure gauge with a zero to 3 psig dial span.** Set over pressure relief device in test air supply line at 2 psi.

CAUTION: Do not leave pressurized tank unattended.

3.2.2 Close valve A.


3.2.3 Connect regulated test air supply line to test piping as shown on Figure 2.

CAUTION: Check to see regulated test air supply line pressure is properly set before proceeding.

3.2.4 Slowly open valve A to pressurize the tank. Pressure gauge 1 should indicate test air pressure of 1-1/2 psig minimum to 2-1/2 psig maximum.

3.2.5 Close valve A. Disconnect regulated test air supply line from piping.

3.2.6 Hold test pressure in tank for 1-hour minimum. A steady drop in pressure reading for gauge 1 indicates there may be a leak in the tank.



3.2.7 Apply approved leak test solution to tank roof welds, fittings, etc. Check for leaks. No leaks are allowed. If leaks are found, notify Highland Tank.

3.2.8 Apply approved leak test solution to tank exterior surfaces, welds, fittings, etc. Check for leaks. No leaks are allowed. If leaks are found, notify the Highland Tank, if no leaks are found, testing of the tank is complete. Proceed with instructions.

3.2.9 Slowly open valve A to release test air pressure from tank.

3.2.10 With tank depressurized, remove test piping, temporary plugs, caps and seals. Reinstall emergency relief vents, etc. If tank is equipped with an emergency vent long-bolt manhole, remove C-clamps.

4.0 Tanks

4.1 All tanks must be UL 142 listed tanks.

4.2 Install all permanent piping and fittings using compatible non-hardening thread sealant material.

4.3 All unused tank openings must be properly sealed using metal threaded pipe plugs, flanges or caps using compatible non-hardening thread sealant material.

4.4 *Do not modify tank structure in any way.*

4.5 *Do not weld on tank.*

5.0 Labeling

5.1 Tanks shall be labeled in accordance with all applicable codes.

DISCLAIMER

Every effort had been made by Highland Tank to ensure the accuracy and reliability of the information contained in these instructions. Highland Tank does not make any representation, warranty or guarantee in connection with the publication of these instructions, and hereby expressly disclaims any liability or responsibility for loss or damage resulting from the use of this instruction; violation of any federal, state or local regulation(s) with which these instructions may conflict; or the infringement of any patent resulting from the use of these instructions. Nor is this instruction meant to provide interpretation of regulatory or legislative requirements in the tank industry.



Please visit us at www.highlandtank.com

One Highland Road
Stoystown, PA 15563
973-696-1300
FAX 814-893-6126

99 West Elizabethtown Road
Manheim, PA 17545
717-664-0600
FAX 664-0617

958 19th Street
Watervliet, NY 12189
518-273-0801
FAX 273-1365

2700 Patterson Street
Greensboro, NC 27407
336-218-0801
FAX 218-1292

2225 Chestnut Street
Lebanon, PA 17042
717-664-0602
FAX 664-0631

1510 Stoystown Road
Friedens, PA 5541
814-443-6800
FAX 444-8662